QR2520W
QR2520X

User manual

Refrigerator

Downloaded from www.Manualslib.com manuals search engine

Thank you for choosing one of our high-quality products.

To ensure optimal and regular performance of your appliance please read this instruction manual carefully. It will enable you to navigate all processes perfectly and most efficiently. To refer to this manual any time you need to, we recommend you to keep it in a safe place. And please pass it to any future owner of the appliance.

We wish you much joy with your new appliance.

CONTENTS

SAFETY INFORMATION 2
- Children and vulnerable people safety 3
- General safety 3
- Daily use 4
- Care and cleaning 4
- Installation 4
- Service 5

CONTROL PANEL 5
- Display/Indicator 5
- Switching on 6
- Switching off 6
- Temperature regulation 6
- Minute Minder function 6
- Child Lock function 7
- COOLMATIC function 7
- Extra Humidity function 7
- Holiday function 8
- Door open alarm 8

FIRST USE 8
- Cleaning the interior 8

DAILY USE 9
- Movable shelves 9
- Vegetable Drawer 9
- Bottle rack 10
- Clean Air Control Filter 10
- Positioning the door shelves 11

HELPFUL HINTS AND TIPS 11
- Hints for energy saving 11
- Hints for fresh food refrigeration 11
- Hints for refrigeration 11
- Hints for temperature inside the fridge 12

CARE AND CLEANING 12
- Periodic cleaning 13
- Replacing the Clean Air Control filter 13
- Cleaning the ventilation grille 13
- Defrosting the refrigerator 14
- Periods of non-operation 14

WHAT TO DO IF... 14
- Replacing the lamp 16
- Closing the door 16

TECHNICAL DATA 16

INSTALLATION 16
- Positioning 17
- Location 17
- Electrical connection 17
- Removing the transport support 17
- Removing the shelf holders 18
- Rear spacers 18
- Fitting the door handles 18
- Levelling 19
- Installation of the Taste Guard Filter 19
- Door reversibility 20

NOISES 21

ENVIRONMENTAL CONCERNS 23

Subject to change without notice

SAFETY INFORMATION

In the interest of your safety and to ensure the correct use, before installing and first using the appliance, read this user manual carefully, including its hints and warnings. To avoid

Downloaded from www.Manualslib.com manuals search engine

unnecessary mistakes and accidents, it is important to ensure that all people using the appliance are thoroughly familiar with its operation and safety features. Save these instructions and make sure that they remain with the appliance if it is moved or sold, so that everyone using it through its life will be properly informed on appliance use and safety.
For the safety of life and property keep the precautions of these user's instructions as the manufacturer is not responsible for damages caused by omission.

Children and vulnerable people safety

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

  Children should be supervised to ensure that they do not play with the appliance.
- Keep all packaging well away from children. There is risk of suffocation.
- If you are discarding the appliance pull the plug out of the socket, cut the connection cable (as close to the appliance as you can) and remove the door to prevent playing children to suffer electric shock or to close themselves into it.
- If this appliance featuring magnetic door seals is to replace an older appliance having a spring lock (latch) on the door or lid, be sure to make that spring lock unusable before you discard the old appliance. This will prevent it from becoming a death trap for a child.

General safety

WARNING!

Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

- The appliance is intended for keeping foodstuff and/or beverages in a normal household as explained in this instruction booklet.
- Do not use a mechanical device or any artificial means to speed up the thawing process.
- Do not use other electrical appliances (such as ice cream makers) inside of refrigerating appliances, unless they are approved for this purpose by the manufacturer.
- Do not damage the refrigerant circuit.
- The refrigerant isobutane (R600a) is contained within the refrigerant circuit of the appliance, a natural gas with a high level of environmental compatibility, which is nevertheless flammable.

  During transportation and installation of the appliance, be certain that none of the components of the refrigerant circuit become damaged.

  If the refrigerant circuit should become damaged:
  - avoid open flames and sources of ignition
  - thoroughly ventilate the room in which the appliance is situated
- It is dangerous to alter the specifications or modify this product in any way. Any damage to the cord may cause a short-circuit, fire and/or electric shock.

WARNING!
Any electrical component (power cord, plug, compressor) must be replaced by a certified service agent or qualified service personnel to avoid hazard.

Downloaded from www.Manualslib.com manuals search engine

1. Power cord must not be lengthened.
2. Make sure that the power plug is not squashed or damaged by the back of the appliance. A squashed or damaged power plug may overheat and cause a fire.
3. Make sure that you can come to the mains plug of the appliance.
4. Do not pull the mains cable.
5. If the power plug socket is loose, do not insert the power plug. There is a risk of electric shock or fire.
6. You must not operate the appliance without the lamp cover[1] of interior lighting.

- This appliance is heavy. Care should be taken when moving it.
- Do not remove nor touch items from the freezer compartment if your hands are damp/wet, as this could cause skin abrasions or frost/freezer burns.
- Avoid prolonged exposure of the appliance to direct sunlight.
- Bulb lamps[2] used in this appliance are special purpose lamps selected for household appliances use only. They are not suitable for household room illumination.

Daily use

- Do not put hot pot on the plastic parts in the appliance.
- Do not store flammable gas and liquid in the appliance, because they may explode.
- Appliance's manufacturers storage recommendations should be strictly adhered to. Refer to relevant instructions.

Care and cleaning

- Before maintenance, switch off the appliance and disconnect the mains plug from the mains socket.
- Do not clean the appliance with metal objects.
- Regularly examine the drain in the refrigerator for defrosted water. If necessary, clean the drain. If the drain is blocked, water will collect in the bottom of the appliance.

Installation

For electrical connection carefully follow the instructions given in specific paragraphs.

- Unpack the appliance and check if there are damages on it. Do not connect the appliance if it is damaged. Report possible damages immediately to the place you bought it. In that case retain packing.
- It is advisable to wait at least four hours before connecting the appliance to allow the oil to flow back in the compressor.
- Adequate air circulation should be around the appliance, lacking this leads to overheating. To achieve sufficient ventilation follow the instructions relevant to installation.
- Wherever possible the back of the product should be against a wall to avoid touching or catching warm parts (compressor, condenser) to prevent possible burn.
- The appliance must not be located close to radiators or cookers.
- Make sure that the mains plug is accessible after the installation of the appliance.
- Connect to potable water supply only. [3]

1) If the lamp cover is foreseen.
2) If the lamp is foreseen.
3) If a water connection is foreseen.

Downloaded from www.Manualslib.com manuals search engine

Service

- Any electrical work required to do the servicing of the appliance should be carried out by a qualified electrician or competent person.
- This product must be serviced by an authorized Service Centre, and only genuine spare parts must be used.

Environment Protection

This appliance does not contain gasses which could damage the ozone layer, in either its refrigerant circuit or insulation materials. The appliance shall not be discarded together with the urban refuse and rubbish. The insulation foam contains flammable gases: the appliance shall be disposed according to the applicable regulations to obtain from your local authorities. Avoid damaging the cooling unit, especially at the rear near the heat exchanger. The materials used on this appliance marked by the symbol ♺ are recyclable.

CONTROL PANEL



1 ON/OFF button
2 Mode button
3 OK button
4 Temperature colder button
5 Temperature warmer button
6 Display

It is possible to change predefined sound of buttons to a loudly one by pressing together Mode button and Temperature colder button for some seconds. Change is reversible.

Display/Indicator



1 Timer indicator
2 COOLMATIC function
3 Holiday function
4 Temperature indicator
5 Alarm indicator
6 Child Lock function

Downloaded from www.Manualslib.com manuals search engine

7 Minute Minder function
8 Humidity function

Switching on

To switch on the appliance do these steps:
1. Connect the mains plug to the power socket.
2. Press the ON/OFF button if the display is off.
3. If "dEMo" appears on the display, the appliance is in demonstration mode. Refer to "What to do if..." paragraph.
4. The temperature indicators show the set default temperature.

To select a different set temperature refer to "Temperature regulation".

⚠ If the door remains open for some minutes, the light will turn off automatically. The light is reset by closing and opening the door itself.

Switching off

To switch off the appliance do these steps:
1. Press the ON/OFF button for few seconds.
2. The display switches off.
3. To disconnect the appliance from the power disconnect the mains plug from the power socket.

Temperature regulation

The set temperature of the fridge may be adjusted by pressing the temperature button.
Set default temperature:
- +5°C for the fridge

The temperature indicator shows the set temperature.
The set temperature will be reached within 24 hours.

⚠ After a power failure the set temperature remains stored.

Minute Minder function

The Minute Minder function is to be used to set an acoustic alarm at the preferred time, useful for example when a recipe requires to cool down a mixture for a certain lenght of time.
To switch on the function:
1. Press the Mode button until the corresponding icon appears.

   The Minute Minder indicator flashes.

   The Timer shows the set value (30 minutes) for a few seconds.
2. Press the Temperature colder or the Temperature warmer button to change the Timer set value from 1 to 90 minutes.
3. Press the OK button to confirm.

   The Minute Minder indicator is shown.

   The Timer start to flash (min).

At the end of the countdown the Minute Minder indicator flashes and an audible alarm sounds:

Downloaded from www.Manualslib.com manuals search engine

1. Press OK button to switch off the sound and terminate the function.

It is possible to deactivate the function at any time during the countdown:

1. Press the Mode button until the Minute Minder indicator flashes.
2. Press the OK button to confirm.
3. The Minute Minder indicator goes off.

It is possible to change the time during the countdown by pressing the Temperature colder button and the Temperature warmer button.

Child Lock function

To lock the buttons from unintentional operation select the Child Lock function.

To switch on the function:

1. Press the Mode button until the corresponding icon appears.
2. The Child Lock indicator flashes.
3. Press the OK button to confirm.

   The Child Lock indicator is shown.

To switch off the function:

1. Press the Mode button until the Child Lock indicator flashes.
2. Press the OK button to confirm.
3. The Child Lock indicator goes off.

COOLMATIC function

If you need to insert a large amount of warm food, for example after doing the grocery shopping, we suggest activating the COOLMATIC function to chill the products more rapidly and to avoid warming the other food which is already in the refrigerator.

To switch on the function:

1. Press the Mode button until the corresponding icon appears.

   The COOLMATIC indicator flashes.
2. Press the OK button to confirm.

   The COOLMATIC indicator is shown.

The COOLMATIC function shuts off automatically after approximately 6 hours.

To switch off the function before its automatic end:

1. Press the Mode button until the COOLMATIC indicator flashes.
2. Press the OK button to confirm.
3. The COOLMATIC indicator goes off.

The function switches off by selecting a different fridge set temperature.

Extra Humidity function

If you need to increase the humidity in the refrigerator, we suggest activating the Extra Humidity function:

To switch on the function:

1. Press the Mode button until the corresponding icon appears.

   The Extra Humidity indicator flashes.
2. Press the OK button to confirm.

   The Extra Humidity indicator is shown.

To switch off the function:

Downloaded from www.Manualslib.com manuals search engine

1. Press the Mode button until the Extra Humidity indicator flashes.
2. Press the OK button to confirm.
3. The Extra Humidity indicator goes off.

Holiday function

This function allows you to keep the refrigerator closed and empty during a long holiday period without the formation of a bad smell.

⚠ The fridge compartment must be empty with holiday function on.

To switch on the function:

1. Press the Mode button until the corresponding icon appears.

   The Holiday indicator flashes.

   The fridge temperature indicator shows the set temperature.
2. Press the OK button to confirm.

   The Holiday indicator is shown.

To switch off the function:

1. Press the Mode button until the Holiday indicator flashes.
2. Press the OK button to confirm.
3. The Holiday indicator goes off.

⚠ The function switches off by selecting a different fridge set temperature.

Door open alarm

An acoustic alarm will sound if the door is left open for a few minutes. The door open alarm conditions are indicated by:

- flashing Alarm indicator
- acoustic buzzer

When normal conditions are restored (door closed), the alarm will stop.
During the alarm, the buzzer can be switched off by pressing any button.

FIRST USE

Cleaning the interior

Before using the appliance for the first time, wash the interior and all internal accessories with lukewarm water and some neutral soap so as to remove the typical smell of a brand-new product, then dry thoroughly.

⚠ Do not use detergents or abrasive powders, as these will damage the finish.

Downloaded from www.Manualslib.com manuals search engine

Check that the drain hose at the rear of the cabinet discharges into the drip tray.



DAILY USE

Movable shelves

The walls of the refrigerator are equipped with a series of shelves support so that the shelves can be positioned as desired.
Some shelves must be lifted up by the rear edge to enable them to be removed.



⚠ Do not move the glass shelf above the vegetable drawer to ensure correct air circulation.

Vegetable Drawer

The drawer is suitable for storing fruit and vegetables.
Some models have a separator inside the drawer that can be placed in different positions to allow for the subdivision best suited to personal needs.
All parts inside the drawer can be removed for cleaning purposes.

Downloaded from www.Manualslib.com manuals search engine

Bottle rack

Place the bottles (with the opening facing front) in the pre-positioned shelf.



If the shelf is positioned horizontally, place only closed bottles.

This bottle holder shelf can be tilted in order to store previously opened bottles. To obtain this result, pull the shelf up so it can rotate upwards and be placed on the next higher level.



Clean Air Control Filter

Your appliance is equipped with a carbon filter behind the air lever flap.
The filter purifies the air from unwanted odours in the fridge compartment preserving food quality.
On delivery the filter is in a plastic bag. Refer to "Installation of the Clean Air Control filter" for instructions.

Make sure that the air lever flap is closed to obtain proper function.

Downloaded from www.Manualslib.com manuals search engine

Positioning the door shelves

To permit storage of food packages of various sizes, the door shelves can be placed at different heights.
To make these adjustments proceed as follows:
Gradually pull the shelf in the direction of the arrows until it comes free, then reposition as required.



⚠ Do not move the big lower door shelf to ensure correct air circulation.

HELPFUL HINTS AND TIPS

Hints for energy saving

- Do not open the door frequently or leave it open longer than absolutely necessary.
- If the ambient temperature is high and the Temperature Regulator is set to low temperature and the appliance is fully loaded, the compressor may run continuously, causing frost or ice on the evaporator. If this happens, set the Temperature Regulator toward warmer settings to allow automatic defrosting and so a saving in electricity consumption.

Hints for fresh food refrigeration

To obtain the best performance:
- do not store warm food or evaporating liquids in the refrigerator
- do cover or wrap the food, particularly if it has a strong flavour
- position food so that air can circulate freely around it

Hints for refrigeration

Useful hints:
Meat (all types) : wrap in polythene bags and place on the glass shelf above the vegetable drawer.
For safety, store in this way only one or two days at the most.
Cooked foods, cold dishes, etc... these should be covered and may be placed on any shelf.

Downloaded from www.Manualslib.com manuals search engine

Fruit and vegetables: these should be thoroughly cleaned and placed in the special drawer(s) provided.
Butter and cheese: these should be placed in special airtight containers or wrapped in aluminium foil or polythene bags to exclude as much air as possible.
Milk bottles: these should have a cap and should be stored in the bottle rack on the door.
Bananas, potatoes, onions and garlic, if not packed, must not be kept in the refrigerator.

Hints for temperature inside the fridge

A suitable temperature inside the fridge is approx. +5° C. When the temperature regulator is set to +5°C this represents the mean temperature in the fridge. It is normal with higher temperature in the top of the fridge.
If the temperature regulator is set to a cold temperature, the ambient temperature is high or if the fridge is fully loaded the compressor will run for a longer time. It too cold, change to a higher temperature setting.



⚠ Do not place food against or close to the temperature sensor. This can result in too cold temperatures.

If you want to check the temperature of food stored in the refrigerator, place a glass of water centrally in the cabinet, and put a proper thermometer with an accuracy of +/– 1 °C into it. After 6 hours the temperature can be monitored. The measuring shall be performed under steady-stated conditions (without changing the load).



CARE AND CLEANING

⚠ **CAUTION!**
Unplug the appliance before carrying out any maintenance operation.

This appliance contains hydrocarbons in its cooling unit, maintenance and recharging must therefore only be carried out by authorized technicians.

Downloaded from www.Manualslib.com manuals search engine

Periodic cleaning

The equipment has to be cleaned regularly.

- clean the inside and accessories with lukewarm water and some neutral soap.
- regularly check the door seals and wipe clean to ensure they are clean and free from debris.
- rinse and dry thoroughly.

⚠ Do not pull, move or damage any pipes and/or cables inside the cabinet.
Never use detergents, abrasive powders, highly perfumed cleaning products or wax polishes to clean the interior as this will damage the surface and leave a strong odour.

Clean the condenser (black grill) and the compressor at the back of the appliance with a brush. This operation will improve the performance of the appliance and save energy consumption.

⚠ Take care of not to damage the cooling system.

⚠ When moving the cabinet, lift it by the front edge to avoid scratching the floor.

Many proprietary kitchen surface cleaners contain chemicals that can attack/damage the plastics used in this appliance. For this reason use a soft cloth rinsed in warm water and neutral soap emulsion for cleaning external surfaces.

⚠ Do not use detergents or abrasive paste as these will damage the paint, or stainless steel anti finger print coating.

After cleaning, reconnect the equipment to the mains supply.

Replacing the Clean Air Control filter

To get the best performance replace the Clean Air Control filter once every year.
New active filters can be purchased from your local dealer.
Refer to "Installation of the Clean Air Control filter" for instructions.

Cleaning the ventilation grille

The ventilation grille can be removed for washing.
Make sure the door is open and then.

1. Loosen the upper edge of the grille by pulling outward/downward.
2. Pull the grille straight out to completely remove it.
3. Vacuum clean under the cabinet.



Downloaded from www.Manualslib.com manuals search engine

Defrosting the refrigerator

Frost is automatically eliminated from the evaporator of the refrigerator compartment every time the motor compressor stops, during normal use. The defrost water drains out through a drain hole into a special container at the back of the appliance, over the motor compressor, where it evaporates.
It is important to periodically clean the defrost water drain hole in the middle of the refrigerator compartment channel to prevent the water overflowing and dripping onto the food inside.



Periods of non-operation

When the appliance is not in use for long periods, take the following precautions:

1. disconnect the appliance from electricity supply
2. remove all food
3. defrost and clean the appliance and all accessories
4. leave the door/doors open to prevent unpleasant smells.

If the cabinet will be kept on, ask somebody to check it once in a while to prevent the food inside from spoiling in case of a power failure.

WHAT TO DO IF...

During operation of the appliance some smaller but annoying trouble can often occur, which does not require calling a technician out. In the following chart information is given about them to avoid unnecessary charges on service.

The operation of the appliance goes with certain sounds (compressor and circulating sound). This not means a trouble, but a normal operation.

The appliance operates discontinuously, so the stopping of compressor does not mean being no current. That is why you must not touch the electrical parts of the appliance before breaking the circuit.

Problem	Possible cause	Solution
The appliance is noisy.	The appliance is not supported properly	Check if the appliance stands stable (all feet and wheels should be on the floor) Refer to "Levelling".
The buzzer sounds. The Alarm icon flashing.	The door is not closed correctly	Refer to "Door open alarm"

Downloaded from www.Manualslib.com manuals search engine

Problem	Possible cause	Solution
▫ upper or lower square is shown in the temperature display.	An error has occurred in measuring the temperature	Call your service representative (the cooling system will continue to keep food products cold, but temperature adjustment will not be possible)
"dEMo" appears on the display.	The appliance is in demonstration mode	Keep pressed approximately 10 sec the OK button since a long sound of buzzer is heard and the display shut off for a short while appliance start works regularly
The compressor runs continuously.	The Temperature regulator may be set incorrectly	Set a warmer temperature
	The door is not closed correctly	Refer to "Closing the door"
	The door has been opened too frequently	Do not keep the door open longer than necessary
	The food temperature is too high	Let the food temperature decrease to room temperature before storage
	The room temperature is too high	Decrease the room temperature
Water flows inside the refrigerator.	The water outlet is clogged	Clean the water outlet
	Food prevent that water flows into the water collector	Make sure that food do not touch the rear plate
Water flows on the ground.	The melting water outlet does not flow in the evaporative tray above the compressor	Attach the melting water outlet to the evaporative tray
The temperature in the appliance is too cold.	The Temperature regulator may be set incorrectly	Set a warmer temperature
The temperature in the appliance is too warm.	The Temperature regulator may be set incorrectly	Set a lower temperature
	The door is not closed correctly	Refer to "Closing the door"
	The food temperature is too high	Let the food temperature decrease to room temperature before storage
The temperature in the refrigerator is too warm.	There is no cold air circulation in the appliance	Make sure that there is cold air circulation in the appliance
	Large quantities of food to be cooled were put in at the same time	Insert smaller quantities of food to be cooled at the same time
The appliance does not operate.	The appliance is switched off	Switch on the appliance

Downloaded from www.Manualslib.com manuals search engine

Problem	Possible cause	Solution
	The mains plug is not connected to the mains socket correctly	Connect the mains plug to the mains socket correctly
	The appliance has no power There is no voltage in the mains socket	Connect a another electrical appliance to the mains socket Check fuse Contact a qualified electrician
The lamp does not work.	The lamp is defective	Refer to "Replacing the lamp"
	The door has been open to long	Close the door
Door interferes with ventilation grill.	The appliance is not levelled	Refer to "Levelling"
Misaligned door.	The appliance is not levelled	Refer to "Levelling"

As much as the advice does not lead to result, call the nearest brand-mark service.

Replacing the lamp

The appliance is equipped with a longlife LED interior light.
Only service is allowed to replace the lighting device. Contact your Service Center .

Closing the door

1. Clean the door gaskets.
2. If necessary, adjust the door. Refer to "Installation".
3. If necessary, replace the defective door gaskets. Contact the Service Center.

TECHNICAL DATA

Dimension		
	Height	1800 mm
	Width	595 mm
	Depth	623 mm
Voltage		230 V
Frequency		50 Hz

The technical information are situated in the rating plate on the internal left side of the appliance and in the energy label.

INSTALLATION

WARNING!
Read the "Safety Information" carefully for your safety and correct operation of the appliance before installing the appliance.

Downloaded from www.Manualslib.com manuals search engine

Positioning

Install this appliance at a location where the ambient temperature corresponds to the climate class indicated on the rating plate of the appliance:

Climate class	Ambient temperature
SN	+10°C to + 32°C
N	+16°C to + 32°C
ST	+16°C to + 38°C
T	+16°C to + 43°C

Location

To ensure best performance, if the appliance is positioned below an overhanging wall unit, the minimum distance between the top of the cabinet and the wall unit must be at least 40 mm . Ideally, however, the appliance should not be positioned below overhanging wall units.

The ventilation space can be:

- directly above the appliance
- behind and above the top cupboard.

  In this case, the space behind the top cupboard must be at least 50 mm deep.



Electrical connection

Before plugging in, ensure that the voltage and frequency shown on the rating plate correspond to your domestic power supply.

The appliance must be earthed. The power supply cable plug is provided with a contact for this purpose. If the domestic power supply socket is not earthed, connect the appliance to a separate earth in compliance with current regulations, consulting a qualified electrician.

The manufacturer declines all responsibility if the above safety precautions are not observed.

This appliance complies with the E.E.C. Directives.

Removing the transport support

Your appliance is equipped with transport support to secure the door during transportation. To remove them do these steps:

Downloaded from www.Manualslib.com manuals search engine

1. Open the door.
2. Remove the transport support from the door sides.
3. Remove the transport support from the lower hinge (some models).



⚠ Some models are fitted with a silencing pad under the cabinet. Do not remove this pad.

Removing the shelf holders

Your appliance is equipped with shelf retainers that make it possible to secure the shelves during transportation.
To remove them proceed as follows:

1. Move the shelf holders in the direction of the arrow (A).
2. Lift up the shelves in the rear edge (B) and push it forward until it is freed (C).
3. Remove the retainers.



Rear spacers

Install the spacers provided within the accessory bag as shown in the figure.
Install the spacers on the back side of the panel.



Fitting the door handles

(Example for right hinge performance)
The handles are supplied as a kit at delivery.

Downloaded from www.Manualslib.com manuals search engine

1. Screw the top handle bracket to the handle rod.
2. Fit the bottom handle bracket on the lower left-hand side of the door.
3. Fit the top handle bracket on the top left-hand side of the door.
4. Screw the handle rod to the bottom handle bracket.



⚠ Do not use excessive force and overtighten the screws (max. 2 Nm) as you may damage the door handles.

Levelling

When placing the appliance ensure that it stands level. If necessary adjust the feet using the adjustment spanner supplied.
Door alignment is dependent on proper levelling.



Installation of the Taste Guard Filter

The Taste Guard Filter is an active carbon filter which absorbs bad odours maintain the best flavour and aroma for all foodstuffs without risk of odour cross contamination.
On delivery the carbon filter is in a plastic bag to preserve performance.

1. Open the air lever flap.
2. Take the filter out of the plastic bag.



Downloaded from www.Manualslib.com manuals search engine

3. Insert the filter in the slot found in the back of the air lever flap.
4. Close the air lever flap.



The filter should be handled carefully so fragments do not loosen from the surface. Make sure that the air lever flap is closed to obtain proper function.

Door reversibility

To change the opening direction of the door, do these steps:

1. Remove the plug from the power.
2. Remove the ventilation grille. Remove the upper filling and install it on the opposite side of the grille.

   Remove the pedal hole cover and install the cover provided in the accessory bag on the opposite side.
3. Lay down the appliance back side down on a wooden support.
4. Remove the handle.

   Unscrew the handle from the top (A1) and the bottom (A2) of the door.

   Unscrew both of the handle brackets from the handle rod and re-screw the handle brackets provided in the handle kit.



5. Unscrew the hinge (B1) and remove the cover plate (B2) and the support (B3).

   Remove the cover (B4) on the opposite side and install the support (B3) the cover plate (B2) and the hinge (B1). Install the cover (B4) on the opposite side.



Downloaded from www.Manualslib.com manuals search engine

6. Unscrew the lower hinge (C1). Move the pin to the opposite side (C2). Unscrew and move the pedal to the opposite side (C3).

   Screw on the lower hinge on the opposite side.
7. Tighten the pin with the adjustment spanner supplied.
8. Install the handle on the opposite side.
9. Raise the appliance and install the ventilation grille.
10. Put the cabinet in position.



WARNING!
Reposition, level the appliance, wait for at least four hours and then connect it to the power socket.

Do a final check to make sure that:
- All screws are tightened.
- The magnetic seal adheres to the cabinet.
- The door opens and closes correctly.

If the ambient temperature is cold (i.e. in Winter), the gasket may not fit perfectly to the cabinet. In that case, wait for the natural fitting of the gasket.

NOISES

There are some sounds during normal running (compressor, refrigerant circulation).



Downloaded from www.Manualslib.com manuals search engine









Downloaded from www.Manualslib.com manuals search engine





ENVIRONMENTAL CONCERNS

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be taken to the appropriate collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local council, your household waste disposal service or the shop where you purchased the product.

Downloaded from www.Manualslib.com manuals search engine

www.aeg.com/shop

CE

298376912-C-192011

Downloaded from www.Manualslib.com manuals search engine